

| Brand | Туре | Launch year | Internal reference | Creation date | Output | Version no. | Page |
|-------|------|-------------|--------------------|---------------|------------|----------------|-------|
| SEAT | LEON | 2024 | VSS-KLG1H50 | 10/04/2024 | 23/07/2024 | 1 | 1 / 4 |



SEAT LEON e-HYBRID

5 doors / 5 seats / hatchback From 2024



1. Identification / recognition



The electric motor does not emit noise. The powermeter on the instrument panel indicates whether the electric motor is disconnected ("OFF") or connected and ready for operation ("READY").



Charging port



Suitable lifting points

Engine compartment



The logo may not be present


2. Immobilisation / stabilisation / lifting

Immobilize the vehicle

- 1. Engage the electric parking brake.
- 2. Switch off the ignition (see chapter 3).
- 3. Secure the vehicle to prevent it from moving.







Suitable lifting points Battery pack, high-voltage

3. Disable direct hazards / safety regulations

Switch off ignition



Press the START - ENGINE - STOP button located in the center console without pressing the brake pedal.



Keep the vehicle key and/or smartphone app further than 5 m away from the vehicle.

High-voltage system deactivation

In case of accidents with airbag deployment, the high-voltage system is automatically and immediately deactivated upon detecting the airbag deployment. The high-voltage is de-energized approxumaately 20 seconds after deactivation



Do not touch, cut, or open damaged high-voltage components, cables, or batteries! Wear appropriate protective equipment!

| Brand | Туре | Launch year | Internal reference | Creation date | Output | Version no. | Page |
|-------|------|-------------|--------------------|---------------|------------|----------------|-------|
| SEAT | LEON | 2024 | VSS-KLG1H50 | 10/04/2024 | 23/07/2024 | 1 | 2 / 4 |



SEAT LEON e-HYBRID

5 doors / 5 seats / hatchback From 2024









Release the cover next to the steering column with a screwdriver

Right-hand drive vehicle:

Pull the tag to disconnect the fuse



Alternative compartment method: from the engine





Disconnecting the 12-volt battery



- 1. Locate the battery cover located on the left side of the trunk.
- 2. Disconnect the negative terminal of the battery from the on-board network by disconnecting the chassis cable.
- Insulate the disconnected cable to avoid 3. contact with the chassis.

Disconnecting the charging station (emergency unlock)




- Locate and pull the yellow ring located on the left 1. side of the engine compartment.
- 2. Disconnect the charger.






4. Access to the occupants



Glass types:

- (1) Laminated safety glass
- (2) Tempered glass

| Brand | Туре | Launch year | Internal reference | Creation date | Output | Version no. | Page |
|-------|------|-------------|--------------------|---------------|------------|----------------|-------|
| SEAT | LEON | 2024 | VSS-KLG1H50 | 10/04/2024 | 23/07/2024 | 1 | 3 / 4 |



| Brand | Туре | Launch year | Internal reference | Creation date | Output | Version no. | Page |
|-------|------|-------------|--------------------|---------------|------------|----------------|-------|
| SEAT | LEON | 2024 | VSS-KLG1H50 | 10/04/2024 | 23/07/2024 | 1 | 4 / 4 |